



Scan Here For More Info

## TECHNICAL DATA SHEET

**Res-protek 810**

## Filter Retainer for Pre-filter 811

### Product Introduction:

UDYOGI | Res-protek 810 Filter Retainer is designed to securely hold 811 particulate filter in place within res-protek 8100 series filters. Its robust design ensures the proper alignment and stability of particulate filter.

### Features:

- **Secure Filter Holding:** Designed to provide a firm grip on filters, preventing displacement and ensuring consistent filtration performance.
- **High Durability:** Made from polyethylene to withstand demanding conditions and ensure long-term reliability.
- **Versatile Compatibility:** Suitable for a wide range of res-protek filters, making it adaptable to different filtration systems.
- **User-Friendly Installation:** Features a straightforward design that allows for easy installation and removal, facilitating maintenance and replacement.
- **Corrosion and Chemical Resistant:** Constructed to resist corrosion and damage from chemicals, extending its service life.

### Benefits:

- **Enhanced Filtration Efficiency:** Ensures filters are properly positioned.
- **Reduced Maintenance Costs:** Simplifies the installation and replacement process, reducing labor costs and downtime associated with filter maintenance.

### Maintenance:

Regularly inspect the filter retainer for signs of damage. Clean periodically to ensure optimal performance and replace as needed.

### Cleaning and Disinfection:

- **Filter Removal:** Remove filters before cleaning the retainer.
- **Cleaning Process:** Clean the retainer with a wet cloth and immerse it in a warm water solution (not exceeding 50°C) using a neutral detergent if necessary.
- **Avoid Harsh Chemicals:** Do not clean with solvents, strong detergents, or petroleum-based products.



### Product Specifications:

<b>Model :</b>	810
<b>Colour:</b>	Transparent
<b>Type of Device:</b>	Filter Retainer
<b>Construction:</b>	Polyethylene
<b>Packing Per Box:</b>	20 pcs
<b>Packing Per Case:</b>	200 pcs

### Usage Instructions:

810 It must be used as a filter retainer with the Res-protek 811 pre-filter along with 8100 series filters.

### Assembly Instructions:

- **Insert the Pre-Filter:** Place the 811 pre-filter into the 810 pre-filter retainer with the printed side of the filter facing up. Press the filter into the retainer until it is securely attached to the filter.
- **Ensure Full Coverage:** The 811 pre-filter must completely cover the face of the filter.



### Storage:

- **Keep in a Cool, Dry Place:** Store the filter in a fresh, cool, and dry environment.
- **Avoid Direct Sunlight:** Keep the filter away from direct sunlight to prevent degradation.
- **Avoid High Heat Sources:** Keep away from high heat sources to maintain filter integrity.